



OVER 35 YEARS OF INNOVATION, QUALITY, SAFETY.

**- SUPER HITCH -
SUPER TRUSS EXTENSION**

IMPORTANT OWNER-OPERATOR INSTALLATION INSTRUCTIONS

D1102-30

APPLICATION FITS
DODGE HD LONG OR SHORT BED WITH FACTORY
INSTALLED RECEIVER



REVISED vers10 BY: DSK 1/8/15

TECH SUPPORT (800) 246-8132

**AFTER INSTALL, PLEASE GIVE
THIS BOOKLET TO YOUR CUSTOMER**


D1102-30 PARTS LIST

- 2 - FRAME SIDE PLATES
- 1 - SINGLE RECEIVER CROSS TUBE
- 1 - 2 x 2 MAGNUM RECEIVER ADAPTER
- 6 - 1/2" STAR WASHERS
- 14 - 1/2" x 2" GRADE 8 HEX BOLTS
- 2 - 1/2" x 1-1/2" GRADE 5 HEX BOLTS
- 8 - 1/2" x 1-1/2" GRADE 8 RIB NECK BOLTS
- 20 - 1/2" GRADE 8 NUTS
- 2 - M14-2.0 CLASS 10.9 HEX NUTS
- 20 - 1/2" FLAT WASHERS
- 20 - 1/2" LOCK WASHERS
- 1 - 1/2" BOLT FISHER
- 2 - 5/8" PIN AND CLIPS
- 2 - 5/16" SELF TAPPING SCREW * "USED FOR WIRE HARNESS AND PLUG BRACKET"
- 2 - 1/2" x 2" ROUND PLATED FLAT WASHERS
- 6 - 2"(5cm) x 2"(5cm) X 5/16" PLATE WASHERS WITH CENTER HOLES
- 2 - 2"(5cm) x 2"(5cm) X 5/16" PLATE WASHERS WITH OFFSET HOLES
- 2 - 2"(5cm) x 2"(5cm) PLATE WASHER WITH LARGE CENTER HOLES
- 6 - 1"(2cm) x 2"(5cm) 1/4" PLATE WASHERS
- 2 - 8-1/2"(22cm) x 2-1/2"(6cm) "SEVEN" SIDE STRAPS
- 2 - 2"(5cm) x 6-1/4"(16cm) TWO HOLE SIDE STRAP

SEE PAGE 17 FOR PROPER RECEIVER FITMENT

ADDENDUM

Modification to the spare tire hanger bracket may be necessary in
installation of SuperHitch



SUPERHITCH PLATES RUN-IN TOWARDS THE CENTER OF THE TRUCK FRAME IN THIS APPLICATION

SHORT BED SPARE TIRE

ADDENDUM

On short bed models fitted with 17"(43cm) tires and wheels, the spare tire will stow away approximately 2"(5cm) lower than it's original position. This lower storage height has been tested and does not present any ground, exhaust or differential clearance issues.

In the event that the original spare tire stowage position is preferred, the spare tire locator loop can be removed. Simply remove the loop by cutting on the marks shown below. Apply a good quality rust inhibiting paint to the cut edge and reinstall the spare tire.



**CUT POINTS
TO
REMOVE
SPARE
TIRE
LOCATOR**



FACING REAR OF TRUCK BED

PLATE WASHER GUIDE



Offset hole plate washer



Center hole plate washer

Offset hole plate washer will be installed into the frame in the oversized factory hole on the bottom rear of the frame **(Hole #3)**.

Center hole plate washer will be used for the oversized hole in the bottom of the frame towards the front of the truck **(Hole #2)**, the side of the truck frame **(Hole #1)**, and as a spacer between the SuperHitch frame plate and 8-1/2" (22cm) x 2-1/2" (6cm) side straps.

SWAYBAR ADDENDUM



Hellwig Swaybar attachment

If you are equipping your truck with a Hellwig swaybar, install as seen above.


SHORT BED ADDENDUM

PASSENGER SIDE

Strap installs at angle



Fastener in this location for a short bed



INSTALLATION INSTRUCTIONS

WITH FACTORY INSTALLED RECEIVER HITCH

WARNING: DO NOT LUBRICATE THREADS, BOLT FAILURE MAY OCCUR DUE TO OVERTIGHTENING. DO NOT DRILL ON THIS HITCH.

NOTE: THIS PRODUCT IS NOT RECOMMENDED FOR USE ON A 1/2-TON VEHICLE.

NOTE: DO NOT REMOVE FACTORY HITCH!!!

WARNING: It is **VERY IMPORTANT** that you read and follow installation instructions on this particular installation. Be sure to identify and familiarize yourself with the hitch and all hardware. Any modification to this hitch will **VOID** your warranty!!!

1. Temporarily remove spare tire.
2. Beginning on the passenger side, fish a 2”(5cm) x 2”(5cm) x 5/16” center hole plate washer (see washer guide on page 4), one 1/2” star washer and 1/2” x 2” hex bolt through Hole #1 (see bolt fishing guide on page 18). All bolt assemblies will be fished through the lower part of the open end of the truck frame.
Note: By putting your hand into the end of the truck frame, you will notice an opening at the top and the bottom of the frame. All bolt assemblies fished into the frame **MUST** pass through the lower opening.
3. Carefully slide the 8-1/2”(22cm) side strap onto the bolt fisher line and onto the bolt. Remove the bolt fisher and loosely install one flat washer, lock washer, and nut. **See Photo B.**
4. Repeat the bolt fishing process with another 2”(5cm) x 2”(5cm) x 5/16” center hole plate washer, one 1/2” star washer and 1/2” x 2” bolt into hole 2.
5. For Hole #3 you will use a 2”(5cm) x 2”(5cm) x 5/16” offset hole plate washer, one 1/2” star washer and a 1/2” x 2” bolt (**See Photos C & D**). Note: The offset hole in the plate washer for Hole #3 **MUST** be installed as in the example found in **Photo C**.
6. Hold the SuperHitch side plate in position as seen in **Photo E**. Be very careful not to push the bolts previously fished back into the frame. Note: for correct SuperHitch side plate installation, see diagram on page 2.
7. Attach the SuperHitch side plate as seen in **Photo F**, utilizing one 1” x 2” plate washer, lock washer and nut for each bolt.
8. Install one 1/2” x 1”(2cm) x 2”(5cm) plate washer and 1/2” x 2” bolt through the bumper bracket and vertical portion of the SuperHitch side plate as in **Photo F and H**.
9. Using a 2”(5cm) x 2”(5cm) x 5/16” center hole plate washer as a spacer (**see Photo G**), attach the 8-1/2” side strap to the SuperHitch side plate using a 1/2” x 2” bolt with 2 flat washers under the head of the bolt, followed by two flat washers, a lock washer and a nut. **See Photos G, H.**

10. Attach the 2”(5cm) x 6-1/4”(16cm) two hole side strap to the previously installed 1/2” bolt through the oval hole in the factory hitch side plate and welded nut to the top left. Place the 2”(5cm) x 2”(5cm) center hole washer over the welded nut and two-hole side strap. Place one 1/2” flat washer on each bolt and one M14-2.0 Class 10.9 Hex nut onto the factory bolt. Place one 1/2” lock washer and one 1/2” Hex nut onto the bottom bolt and hand tighten.

!! DO NOT TIGHTEN ANY FASTENERS UNTIL FINAL STEP!!

11. Repeat Steps 2 through 8 on the driver side.

12. Install one rib neck bolt into the SuperHitch side plate and attach the SuperHitch cross tube with one 1/2” lock washer and nut. **See Photos J and K.** (Do not use an impact to draw in the rib neck bolts as they may end up spinning. Use a mallet and hammer them in until you are able to get the 1/2 lock washer and nut on. Threads should face outwards

13. Repeat Step 10 on driver side as seen in **Photos L and M.**

14. Loosely install the remaining 8 rib neck bolts on both the driver and passenger sides. (Do not use impact to draw in rib neck bolts, use a mallet and hammer them in.) If installing an R series tie down, use a 1/2" x 2" grade 8 bolt in the two holes forward of the cross tube on both sides. **See Photo N.**

15. Attach the SuperHitch receiver to the factory receiver using a 1/2” x 1 1/2” bolt with 1/2” x 2” round plated flat washer and two 1/2” flat washers (as spacers) followed by one flat washer, lock washer and nut on both the driver and passenger side. **See Photos O and P.** All fasteners should be loosely installed at this time.

16. Use a straight edge to align the SuperHitch receiver so that both receiver hitches are in alignment vertically. Using two 3/4” wrenches, snug (do not tighten) the two 1/2” x 1 1/2” bolts to hold the two receiver hitches in proper alignment. **See Photo Q.**

17. Torque down the rib neck bolts to 75 ft. lbs.(101nm)

18. Tighten the rear-most (Hole #3) SuperHitch side plate bolts followed by the forward (Hole #2) bolts (**see Photo S**). Torque down the rear-most horizontal bolts (visible in **Photo R**) and then the forward 8 1/2”(22cm) side strap bolts. All of these should be torqued to 60 ft. lbs. (81nm)

19. Torque the two 1/2” x 1 1/2” bolts attaching the two hitch receivers in step 14.

Photo A




Photo B




Photo C




Photo D



Photo E




Photo F




Photo G




Photo H




Photo I




Photo J




Photo K



Photo L



Photo M



Photo N




Photo O




Photo P




Photo Q



Photo R





Photo S




There is a special notch on the top of the SuperHitch receiver collar for the factory hitch to receiver to fit into, allowing for the chain plate on the factory hitch and Companion plate to sit flush.



TORKLIFT'S BOLT FISHING GUIDE

Your guide to understanding the installation of our frame mounted tie downs.




-Coiled End of Bolt Fisher-

Note: The hardware may vary as to what is being fished along with the bolt. In this instance a 1"(2cm) X 2"(5cm) plate washer is being fished along with the hex bolt. Different applications may require fishing through various star washers and flat washers for example.

Desired Hole on Vehicle (Place the coiled end of the bolt fisher through this hole).

This side of the Bolt Fisher should come out of a hole where the required hardware (for example 1"(2cm) X 2"(5cm) plate washer) can pass through.



This bottom example shows the bolt when it's completely fished through the vehicle. You may find it easier to keep the bolt fisher attached until you get the tie down receiver in place so that the bolt doesn't fall into the vehicle frame.

WARNING: PULLING TOO HARD ON THE BOLT FISHER CAN RESULT IN LOST FASTENERS, OR BROKEN BOLT FISHER.

SUPERTRUSS EXTENSION WEIGHT CAPACITIES

(SUPERTRUSS SOLD SEPARATELY)

ASSEMBLE THE CHAIN, BOW SHACKLES, & TURNBUCKLES

AS SHOWN. TIGHTEN BOW SHACKLES AND

TURNBUCKLE JAM NUTS WITH HAND TOOLS

(TIGHTEN TURNBUCKLES BY HAND

DO NOT USE TOOLS TO TENSION TURNBUCKLES)



WARNING - READ CAREFULLY


Dead Weight (weight carrying) Weight Distributing (load equalizing)

Extension Length	Tongue Weight	Pull Weight	Tongue Weight	Pull Weight
60" (152cm)	500 lb.(226kg)	5,000 lb.(2267kg)	1,000 lb.(453kg)	10,000 lb.(4535kg)
48" (122cm)	600 lb.(272kg)	6,000 lb.(2721kg)	1,200 lb.(544kg)	12,000 lb.(5443kg)
42" (107cm)	600 lb.(272kg)	6,000 lb.(2721kg)	1,200 lb.(544kg)	12,000 lb.(5443kg)
36" (91cm)	650 lb.(294kg)	6,500 lb.(2948kg)	1,200 lb.(544kg)	12,000 lb.(5443kg)
32" (81cm)	650 lb.(294kg)	6,500 lb.(2948kg)	1,200 lb.(544kg)	12,000 lb.(5443kg)
28" (71cm)	750 lb.(340kg)	7,500 lb.(3401kg)	1,200 lb.(544kg)	12,000 lb.(5443kg)
24" (61cm)	750 lb.(340kg)	7,500 lb.(3401kg)	1,400 lb.(635kg)	14,000 lb.(6350kg)
21" (53cm)	750 lb.(340kg)	7,500 lb.(3401kg)	1,400 lb.(635kg)	14,000 lb.(6350kg)

THE USE OF THIS PRODUCT WITHOUT A LOAD EQUALIZING SYSTEM LIMITS YOUR CAPACITY TO THE DEAD WEIGHT (WEIGHT CARRYING) CAPACITY. FAILURE TO STAY WITHIN THESE LIMITATIONS WILL RESULT IN DAMAGE AND VOID YOUR WARRANTY!!!!

The Torklift SuperTruss Extension cannot be used with any other type of trailer hitch receiver. Any attempt to modify or recreate a SuperHitch receiver will result in a loss of warranty. The modification of another factory or aftermarket trailer hitch receiver in an attempt to use a Torklift SuperTruss extension can result in death or damage. The SuperHitch receiver made by Torklift is a special extra heavy-duty trailer hitch receiver, and the capacities stated for the SuperTruss extension are solely with the use of a Torklift SuperHitch. Please call if you have any questions on installs or otherwise at 1-800-246-8132.

**THESE STEPS MAY VARY DEPENDING ON
WEIGHT DISTRIBUTION HITCH
MANUFACTURER
WEIGHT DISTRIBUTING
(LOAD EQUALIZING HITCH)**



**THIS TYPE OF HITCH IS REQUIRED IN
ADDITION TO YOUR SUPERHITCH TO
OBTAIN THE MAXIMUM RATED CAPACITY.
INCORRECT INSTALLATION OF THE WEIGHT
DISTRIBUTION SYSTEM MAY RESULT IN DAMAGE
TO YOUR VEHICLE.**

WEIGHT DISTRIBUTION - CONTINUED

When towing trailers that exceed the dead weight rating on your extension it is mandatory to use a weight distributing type hitch/ball mount and related hardware (SPRING BARS, QUICK HOOKUP CLIPS ETC).


Not all weight distribution systems are rated at the same capacity. Your weight distributing ball mount and bars must be rated at least 100 lbs.(45kg) higher in regards to tongue weight, than your pre-existing tongue weight of your trailer **when fully loaded.**

It is of critical importance that your weight distribution system is not only rated high enough to match your existing tongue weight, but that you also have the system set up correctly.

We have supplied a formula to assist you in accurately determining the tongue weight load of your trailer when fully loaded. After accurately determining your tongue weight and making sure that your weight distribution system is rated high enough, your next step is to ensure the set up of the system is correct.

PLEASE READ CAREFULLY

1. The height of the ball must be determined before any assembly work can be started. To get ball height, measure trailer from ground level to top of ball coupler. Be sure trailer is parallel to ground. With your camper on your truck, fully loaded with gear and overloads adjusted, slide the weight distribution ball mount into the SuperHitch extension. Be sure the truck is on level ground. The measurement from ground to top of ball should be 1 1/2"(4cm) higher than the level height of trailer top of ball measurement.



2. After ball height has been determined write down the ascertained height. EXAMPLE: Measured top of coupler height was 17"(43cm) from ground; ball height should be 18 1/2"(47cm).

3. Slide the shank into the sleeve receiver, insert hitch pin and spring clip. With the ball attached to the ball mount, slide the ball mount up or down the shank until nearest dimension is obtained and the holes line up with shank. Insert the bolt in the bottom hole first (rest hitch head).



4. The rivet and 8 spacer washers are supplied in order to gain the correct downward angle of the spring bars. Insert rivet, and depending on the angle or the slope of bars that must be gained, use either 8 or the least amount of washers necessary in order to establish correct angle. The rivet and its accompanying washers are placed in the 1/2" hole between the "U" on the ball mount to acquire desired angle of spring bar. Once the spring bar angle has been determined, insert the top bolt with a flat washer, both sides, the lock washer, and nut to secure the unit in correct position, now insert the bottom bolt, use the lock washer and nut. Before tightening the bolts, lock the setscrew. (After the first day of towing, check set the screw for tightness).

See the following page for further illustrated diagrams

ILLUSTRATED DIAGRAMS

BEFORE HOOKING UP


Spring bar should hang down on a 10-13 degree angle when ball mount has been tilted back at 6-8 degree angle.




AFTER HOOKING UP

Spring bar should be parallel with trailer frame, or a slight angle up or down. Slight bow or bend to bar is normal.


WRONG Readjust degree of tilt on ball mount, if you have more than 5 links of chain hanging free. The number of links should be the same on both bars.



EACH WASHER LOWERS
CHAIN END OF SPRING
BAR APPROX. 1-1/2"





MAXIMUM
TILT DOWN
WITH 8
WASHERS
ON RIVET



MAXIMUM TILT
UP WITH RIVET
ONLY


BOLT-TOGETHER BALL
MOUNT HAS 7-1/2" AD-
JUSTMENT, EACH AD-
JUSTMENT IS 1-1/4"
EXTRA HY-LOW SHANKS
AVAILABLE IF NEEDED



THESE STEPS MAY VARY DEPENDING ON WEIGHT DISTRIBUTION HITCH MANUFACTURER

1. Put the ball mount into the sleeve and insert the 5/8" hitch pin using spring clip to lock the pin into place, hitch balls are not furnished with the hitch as there are several sizes. Normally they are supplied or may be purchased from the dealer to match the coupler of the trailer. Ball shank bushings are supplied to reduce the size of the ball hole in the hitch down to 1"(2cm) if needed.


2. Measure the towing vehicle ball height before adding load to towing vehicle. Hook the trailer to the truck. Lock on the ball. To make hooking up easier and safer - raise front of the trailer and back of the towing vehicle above level with the trailer tongue jack. This removes some of the tension by reducing the distance between the spring bar and hook-up arm.



3. This step may vary depending on the manufacturer. The spring bars can be inserted into either side of the ball mount. (There is no 'right' or 'left' bar). To insert and lock spring bar in socket, hold the bar under socket and push up. The spring bar will automatically be locked into position by the spring bar-locking device. (Check to make sure the bar is locked in by moving it up and down at the chain end.) To remove the spring bars, just pull out the locking device or swing the bar around under the bumper and it will drop free.

4. To find correct location on trailer frame for quick hook-up bracket, hold the chain straight up and down and free of twist center hook-up bracket on frame and tighten. Set the screw 1/4 turn only. **DO NOT OVERTIGHTEN.** On straight tongue trailers a poli-tongue adapter is necessary

5. You are now ready to put tension on the spring bars. When using the quick hook-up, lower the arm and slip link of chain over hook. Insert hook-up handle over the end of the quick hook-up arm. Lift and flip over center. (See fig A).



CAUTION: MAKE SURE THAT THE HOOK-UP ARM IS COMPLETELY SEATED AND THAT THE SPRING BAR IS PUSHED DIRECTLY UNDER THE HOOK-UP CHAIN HOOK. Now install the hook-up locking clip through locking ears and over hook on hook-up arm. (See fig B)

6. Release the trailer tongue jack by adjusting the chain links up or down; the desired load on the bars will be gained. Now lock the coupler on to the ball and raise the front of the trailer approximately 3"(8cm) above level. Now attach the chain link to the hook-up clip. It should require 50-100 lbs.(22-45kg) of force to properly tension the spring bars. Bow or bend to the spring bar is normal.


7. To release tension on the spring bars, raise the front of the trailer and the back of the towing vehicle above level (approx. 3"(8cm)) with the trailer tongue jack. Remove the locking clip from the bracket. Insert the handle over arm. Carefully lower the arm with the handle. It will require effort to bring the arm over the center and then to resist the chain tension as the arm rotates downward.

MAINTENANCE:


Use heavy lubrication such as fibre type wheel bearing grease on the hitch ball and on spring bars inside the ball mount. This is recommended every day. Also keep the hitch painted to prevent rust and check the tightness of bolts regularly. Clean out old grease and do not let it harden inside of the ball mount

IMPORTANT CONSUMER INFORMATION ON TOWING

TOWING EQUIPMENT OWNERS: Make sure all of the operators of your equipment read and understand this information before towing. Save for reference. This will help you properly select, use, and maintain your towing equipment. Refer to your owner's manuals for your tow vehicle, trailer, and other parts of your towing system. Learn the capabilities and limitations of each part. The **GROSS TRAILER WEIGHT** and **TONGUE WEIGHT** are two of the most important items to consider. **THESE WEIGHTS MUST NEVER EXCEED THE LOWEST RATING OF ANY PART OF YOUR TOWING SYSTEM.** **GROSS TRAILER WEIGHT** is the weight of the trailer plus all cargo. Measure the **GROSS TRAILER WEIGHT** with the fully loaded trailer on a level surface. The weight is the downward force exerted on the ball by the trailer coupler. Measure the **TONGUE WEIGHT** with the fully loaded trailer on a level surface. The coupler must be at its normal towing height. Use a commercial scale or a bathroom scale. Set up the bathroom scale as shown for heavy tongue weights.



**Method for Measuring
Gross Trailer Weight**



**Method for Measuring
Trailer Tongue Weight**

YOUR TOWING EQUIPMENT

HITCH BALLS

Select by gross trailer weight rating, mounting platform thickness, hole size and coupler socket size. Platform must be at least 3/8 inch thick. Hole must not exceed threaded shank diameter by more than 1/16 inch. Use lock washer. Tighten per instructions. When tightened, shank must protrude beyond bottom of nut. Gross trailer weight rating and ball diameter are marked on Hitch balls.

TRAILER COUPLERS

The coupler socket should be smooth, clean and lightly lubricated. Tighten or adjust per coupler manufacturer's instructions.

SAFETY CHAINS

Connect safety chains properly EVERY TIME YOU TOW. Cross chains under coupler. Attach securely to the hitch or tow vehicle so they can't bounce loose. Leave only enough slack to permit full turning. Too much slack may prevent chains from maintaining control if other connections separate. Don't let chains drag on the road.

TRAILER LIGHTS, TURN SIGNALS, ELECTRIC BRAKES AND BREAK AWAY SWITCH CONNECTIONS

Make these safety-critical connections EVERY TIME YOU TOW, no matter how short the trip. Check operation, including electric brake manual control, before getting on the road.

SWAY CONTROLS

Sway controls can lessen the effects of sudden maneuvers, wind gusts and buffeting caused by other vehicles. We recommend them for trailers with large surface areas, such as travel trailers. Adjustable friction models can help control trailers with low tongue weight percentage.

OTHER USEFUL EQUIPMENT

AIR SPRINGS, AIR SHOCKS or HELPER SPRINGS are useful for some hitch applications. A TRANSMISSION COOLER may be necessary for heavy towing. Many states require TOWING MIRRORS on both sides.

TIRE INFLATION

Check often. Follow tow vehicle and trailer manufacturer's recommendations. Improper tire inflation can cause trailer sway.

NO PASSENGERS IN TRAILERS: NEVER allow people in trailers while towing, under any circumstances.

HELPFUL TOWING HINTS

TRAILER LOADING

Proper loading helps prevent sway. Place heavy object on the floor ahead of the axle. Balance the load side-to-side. Secure it to prevent shifting. Tongue weight should be 10-15 percent of gross weight for most trailers. Too low a percentage of tongue weight can cause sway. NEVER load the trailer rear heavy. LOAD THE TRAILER HEAVIER IN FRONT

DRIVING

The additional weight of a trailer affects acceleration, braking, and handling. Allow extra time for passing, stopping, and changing lanes. Severe bumps can damage your towing vehicle, hitch, and trailer. Drive slowly on rough roads. STOP AND MAKE A THOROUGH INSPECTION IF ANY PART OF YOUR TOWING SYSTEM STRIKES THE ROAD. CORRECT ANY PROBLEMS BEFORE RESUMING TRAVEL.

CHECK FOR EXCESSIVE SWAY AND ELIMINATE IT

Excessive sway can lead to loss of control. Sway motion should settle out quickly. Sway tends to increase on a downgrade. Starting slowly, increase speed in gradual steps. If sway occurs, adjust your trailer load and equipment. Repeat until the trailer is stable at highway speed. Do this whenever your trailer loading changes.

IF TRAILER SUDDENLY STARTS TO SWAY

Turbulence from another vehicle, a wind gust, or a downgrade can cause sudden sway. So can a shift of the trailer's load or a trailer tire blowout. IF THE TRAILER SWAYS, IT IS THE DRIVER'S RESPONSIBILITY TO ASSESS THE SITUATION AND TAKE APPROPRIATE ACTION. Below are suggestions that may apply, depending on conditions:

DO

- Reduce your speed gradually
- Hold the steering wheel as steady as possible
- If your trailer has electric brakes, apply the brakes alone, without using the tow vehicle's brakes.

DON'T

- Don't hit your brake pedal hard unless absolutely necessary. A "jack-knife" can result.
- Don't try to steer out of the sway condition. Sudden or violent steering can make it worse.
- Don't speed up. Sway increases as you go faster.
- Don't continue towing a trailer that tends to sway. You may lose control during an emergency maneuver or if the conditions listed above occur.

INSTRUCTIONS FOR FINISH MAINTENANCE

OF TORKLIFT PRODUCTS

POWDER COATED STEEL:

To keep your Torklift products looking good follow these guidelines. All steel powder coated Torklift products are sandblasted for maximum adhesion and use a high quality industrial urethane based powder coat. Due to the extreme, harsh, under car environment that your Torklift products live in, (constantly sprayed with corrosive road chemicals such as salt, and road debris), Torklift does not warranty the powder coated finish.

To minimize corrosion from these factors on powder coated steel products, Torklift recommends regularly cleaning and inspecting the powder-coated surface and touching up any affected areas with enamel or urethane based aerosol paint product. If there are any areas of surface rust, there are also aerosol spray rust converters available on the market that can be used as a preparation to touch-up paint application. These finish maintenance products are available at any automotive parts supplier.

POLISHED STAINLESS STEEL:

Torklift utilizes quality grade 304 stainless steel in our stainless steel polished products. 304 stainless steel is well known for its anti-corrosive properties.

However, in some environments such as coastal regions or when coming in contact with some road chemicals, corrosion may occur.

For a quick clean simply use WD-40 and a cloth rag. We also recommend occasional polishing of our polished stainless products to maintain their attractive finish. Use an approved stainless steel chrome or aluminum mag wheel polish cleaning product, which can be purchased from any automotive parts supplier.

Torklift International Limited Lifetime Warranty Information

322 N. Railroad Ave. Kent, WA 98032

Torklift will require proof of purchase to register, with pictures of any defective product before issuing a replacement. Torklift will not register any product without proof of purchase, which can be faxed, scanned, emailed, or mailed to the information provided below. Torklift warrants it's hitches, custom hitch receivers, frame mounted tie downs, turnbuckles, and accessories (excluding wire harnesses which carry a 90 day warranty) from date of purchase against defects in material and workmanship under normal use and service for the ownership life of the original consumer purchaser. ALL COMMERCIAL APPLICATIONS ARE WARRANTED FOR A PERIOD OF 90 DAYS FROM THE DATE OF INSTALLATION/SERVICE. Torklift will replace FREE OF CHARGE any part, which proves defective in material or workmanship when presented to Torklift, TRANSPORTATION CHARGES PREPAID by purchaser, at the address above. THIS WARRANTY IS LIMITED TO DEFECTIVE PARTS REPLACEMENT ONLY. LABOR CHARGES AND/OR DAMAGE INCURRED IN INSTALLATION OR REPLACEMENT, AS WELL AS INCIDENTAL AND CONSEQUENTIAL DAMAGES CONNECTED THEREWITH ARE EXCLUDED. This warranty does not include the finish or paint on our products. Rusting, cracking or peeling of the finish is also excluded. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Any damage to Torklift products as a result of misuse, abuse, neglect, accident, improper installation or any use violation of instructions furnished by Torklift or WHEN USED IN ANY COMMERCIAL APPLICATION WILL VOID THE WARRANTY. This warranty gives you specific legal rights, and you may also have rights, which vary from state to state. With warranty service, you may be able to go to a small claims court, a state court or a federal district court.



OVER 35 YEARS OF INNOVATION, QUALITY, SAFETY.

322 N. Railroad Ave. Kent, WA 98032

Phone (800) 246-8132

Fax (253) 854-8003

or visit our website: www.TorkLift.com

Dear Valued Customer,

Thank you for making TorkLift your choice for truck, camper packages and accessories for your vehicle. By choosing TorkLift products, you have chosen a company that has been serving the RV industry for nearly 40 years and whose name has become synonymous with strength, quality and advanced design and installation.

Please take a few moments of your time to complete the Product Registration Warranty Card on the next page. When registering your newly purchased TorkLift products, you can be assured that your contact information is secure and that you and your product are getting the attention and respect that you deserve.

Thank you again for choosing TorkLift quality products.

**Register for your lifetime warranty and receive a free Torklift
International gift.**

To Fax: Send copies of the questionnaire, warranty card and receipt to
253-854-8003

To E-mail: Send copies of the questionnaire, warranty card and receipt to
warranty@torklift.com

To Mail: Send to Torklift International 322 N Railroad Ave. Kent, WA 98032



OVER 35 YEARS OF INNOVATION, QUALITY, SAFETY.

OFFICIAL WARRANTY REGISTRATION CARD

PLEASE FILL OUT THIS FORM COMPLETELY AND RETURN TO TORKLIFT WITHIN
30 DAYS OF PURCHASE ACCOMPANIED BY A COPY OF YOUR ORIGINAL RECEIPT

TODAY'S DATE: _____

1. PART(S) PURCHASED

PART#: _____ PART#: _____
PART#: _____ PART#: _____

2. PURCHASER INFORMATION

NAME: _____

ADDRESS: _____

CITY: _____ STATE: _____ ZIP / POSTAL CODE: _____

PHONE: (____) _____ - _____ EMAIL: _____

3. TRUCK INFORMATION

YEAR: _____ MAKE: _____

MODEL: _____ BED LENGTH: _____

4. CAMPER INFORMATION

YEAR: _____ MAKE: _____ MODEL: _____

5. DEALER INFORMATION

PURCHASED FROM: _____

ADDRESS: _____

CITY: _____ STATE: _____ ZIP / POSTAL: _____

INSTALLED BY: ☐ OWNER ☐ ABOVE DEALER ☐ ANOTHER DEALER

IF ANOTHER DEALER, WHO: _____