



Custom Fifth Wheel Brackets Kits

- Cuts install time by up to 50%
- Reduces or eliminates drilling
- Provides a custom fit
- To be used in combination with 16104/16204 rails. No need for universal brackets and hardware
- Rail mounting hardware included

Make/Model	Style	Years From	Years To	Bracket Kit#	Notes	Base Rails Needed			
						Carbide	Black		
CHEVROLET/GMC									
1500/2500LD Silverado/Sierra	New Body	2007	2015	16414	No Drill	16204	16104		
		2007	2014	16412*	No Drill	16204	16104		
2500HD/3500 Silverado/Sierra	Classic Body	1999	2007	16418	Drill	16204	16104		
		2011	2015	16413	No Drill	16204	16104		
		2001	2010	16418	Drill	16204	16104		
DODGE/RAM									
Ram 1500	Excluding Air Bag Suspension	2011	2015	16306	Drill	16204	16104		
	Excluding Crew Cab	2009	2010	16422	Drill	16204	16104		
	Mega Cab	2006	2008	16420	No Drill	16204	16104		
Ram 2500	Excluding Mega Cab	2002	2008	16419	No Drill	16204	16104		
	Without Factory Prep Package	2014	2015	16427	No Drill	16204	16104		
Ram 3500		2013	2013	16426	No Drill	16204	16104		
		2003	2012	16420	No Drill	16204	16104		
		2013	2015	16426	No Drill	16204	16104		
2003		2003	2012	16420	No Drill	16204	16104		
		FORD							
		F-150	6.5' & 8' Beds	2015	2015	16442	No Drill	16204	16104
2004	2014			16441	No Drill	16204	16104		
F-150 Heritage Edition	Heritage Edition	1997	2003	16437	No Drill	16204	16104		
F-250LD	New Body	2004	2004	16437	No Drill	16204	16104		
F-250 & F-350 Super Duty		1997	2003	16437	No Drill	16204	16104		
		2011	2015	16424	No Drill	16204	16104		
		2005	2010	16448	Drill	16204	16104		
F-450 Super Duty	Excluding Cab & Chassis	1999	2004	16443	Drill	16204	16104		
		2011	2015	16424	No Drill	16204	16104		
		2008	2010	16448	Drill	16204	16104		
NISSAN									
Titan		2004	2015	16470	Drill	16204	16104		
TOYOTA									
Tundra	6' 5" Bed, Excluding Crew Max Standard Cab, Long Box	2007	2015	16468	Drill	16204	16104		
		2000	2006	16465	No Drill	16204	16104		

* Continued while supplies last.

Semi-Custom Fifth Wheel Bracket Kits

- To be used in combination with 16100/16200 Rails, Hardware, and Brackets for a semi-custom fit
- Drilling required
- *Except 16300 & 16306. Includes all necessary mounting hardware. Use with 16104 or 16204 rails.

Make/Model	Style	Years From	Years To	Bracket Kit#	Notes	Base Rails Needed	
						Carbide	Black
DODGE							
Ram 1500	Excluding Air Bag Suspension	2009	2015	16306	Drill	16204	16104
		2002	2008	16303	Drill	16200	16100
Ram 2500 & 3500		2003	2012	16301	Drill	16200	16100
FORD							
F-150	Excluding Heritage Edition	2004	2011	16300*	Drill	16204	16104
TOYOTA							
Tundra	6' 5" & 8' Beds, Excluding Crew Max Standard Cab, Long Box	2007	2008	16304	Drill	16200	16100
		2000	2006	16302	Drill	16200	16100

Universal Fifth Wheel Base Rails

Part #	Description	Finish
16100	2 Universal Fifth Wheel Base Rails (Includes Rails, Brackets, and Hardware)	Gloss Black
16104	2 Universal Fifth Wheel Base Rails Only (Brackets & Hardware Kit not included)	Gloss Black
16200	2 Universal Fifth Wheel Base Rails (Includes Rails, Brackets, and Hardware)	Carbide Black
16204	2 Universal Fifth Wheel Base Rails Only (Brackets & Hardware Kit not included)	Carbide Black

16101	Universal Fifth Wheel Rail Mounting Kit. Universal brackets and hardware included	
-------	---	--