

Make & Model	Type	Years	Bulk w/o Quick Plug	Pkg. w/o Quick Plug	Bulk Quick Plug#	Pkg. Quick Plug#	Install Time	Harness Location
			New#	New#	New#	New#		
BUICK								
Enclave		08-12	51420	51421	51422	51423	5	BH1
CADILLAC								
Escalade		14-15	-	-	51451	51452	5	BH3
		03-06	51350	51351	51352	51353	5	BH3
		2002	51340	51341	51342	51343	5	BH3
CHEVROLET/GMC								
Acadia		07-15	51420	51421	51422	51423	5	BH1
Avalanche		03-06	51350	51351	51352	51353	5	BH3
		2002	51340	51341	51342	51343	5	BH3
		2002	51340	51341	51342	51343	5	BH3
CHEVROLET/GMC								
Acadia		07-15	51420	51421	51422	51423	5	BH1
Avalanche		03-06	51350	51351	51352	51353	5	BH3
		2002	51340	51341	51342	51343	5	BH3
		2002	51340	51341	51342	51343	5	BH3
Silverado/Sierra		14-15	-	-	51451	51452	5	BH1
	New Body	07-13	Truck is not equipped with a brake control harness. Hardwire #51515 to blunt cut wires under dash.					
	Classic Body	2007	51350	51351	51352	51353	5	BH3
		03-06	51350	51351	51352	51353	5	BH3
Tahoe		99-02	51340	51341	51342	51343	5	BH3
		2015	51350	51351	51451	51452	5	BH3
		03-06	51350	51351	51352	51353	5	BH3
	New Body w/Amber Turn Signals	00-02	51340	51341	51342	51343	5	BH3
		03-06	51350	51351	51352	51353	5	BH3
Suburban, Yukon		03-06	51350	51351	51352	51353	5	BH3
Yukon XL & Denali	New Body w/Amber Turn Signals	00-02	51340	51341	51342	51343	5	BH3
Traverse	w/Factory Tow Package	09-16	51420	51421	51422	51423	5	BH3
CHRYSLER								
Aspen	w/Factory Tow Package	07-09	51330	51331	51332	51333	5	BH1
DODGE/RAM								
Dakota	w/Factory Tow Package	97-11	51330	51331	51332	51333	5	BH1
Durango	w/Factory Tow Package	11-15	51444	51445	51446	51447	5	BH8
		98-09	51330	51331	51332	51333	5	BH1
		13-14	-	-	-	51453	10	BH8
Ram 1500		2015	-	-	51438	51439	5	BH8
		10-12	-	-	51438	51439	5	BH8
		13-14	-	-	-	51453	10	BH8
Ram 2500		13-14	-	-	-	51453	10	BH8
		10-12	-	-	51438	51439	5	BH8
		13-14	-	-	-	51453	10	BH8
Ram 3500		10-12	-	-	51438	51439	5	BH8
Ram Pickup	All Full Size Pickups	95-09	51330	51331	51332	51333	5	BH1
FORD								
Bronco	Full Size	94-96	51320	-	51322	51323	5	BH2
Econoline Van		92-93	51310	-	51312	51313	5	BH1
		09-14	51430	51431	51432	51433	5	BH5
		92-08	51320	-	51322	51323	5	BH1
Excursion		00-05	51320	-	51322	51323	5	BH2
Expedition		13-14	51430	51431	51432	51433	5	BH5
		97-12	51320	-	51322	51323	5	BH2
Explorer	w/Factory Tow Package	02-11	51320	-	51322	51323	5	BH2
F-150	New Body Heritage Edition	09-15	51434	51435	51436	51437	5	BH7
		04-08	51320	-	51322	51323	5	BH2
		2004	51320	-	51322	51323	5	BH2
F-150 & F-250 Light Duty		94-03	51320	-	51322	51323	5	BH2
F-250 & F-350 Super Duty		08-16	51430	51431	51432	51433	5	BH5
		05-07	51370	51371	51372	51373	5	BH4
		99-04	51320	-	51322	51323	5	BH2
F-250 & F-350 Heavy Duty		1997	51320	-	51322	51323	5	BH2
F-150, F-250, F-350		94-96	51320	-	51322	51323	5	BH2
F-Series Full Size Truck		92-93	51310	-	51312	51313	5	BH1
F-450 & F-550 Super Duty		08-14	51430	51431	51432	51433	5	BH5
		05-07	51370	51371	51372	51373	5	BH4
		12-13	51434	51435	51436	51437	5	BH7
Flex	w/Factory Tow Package	09-11	51320	-	51322	51323	5	BH2
Windstar	w/Factory Tow Package	95-03	51320	-	51322	51323	5	BH2
HONDA								
Pilot		09-16	51390	51391	51392	51393	5	BH1
Ridgeline	w/Factory Tow Package	06-14	51390	51391	51392	51393	5	BH1
HUMMER								
H2		03-07	51350	51351	51352	51353	5	BH3
INFINITI								
QX56		04-13	51380	51381	51382	51383	5	BH1
JEEP								
Grand Cherokee	w/Factory Tow Package	11-15	51444	51445	51446	51447	5	BH8
KIA								
Borrego		09-11	51440	51441	51442	51443	5	BH1
LAND ROVER								
LR3		05-09	51320	-	51322	51323	5	BH2
LR4		10-14	51320	-	51322	51323	5	BH2
Range Rover	Including Sport	05-15	51320	-	51322	51323	5	BH2
Range Rover Evoque		12-14	51320	-	51322	51323	5	BH2
LEXUS								
GX460		10-12	51360	51361	51362	51363	5	BH1
GX470		03-11	51360	51361	51362	51363	5	BH1
LX470		03-07	51360	51361	51362	51363	5	BH1
LX570		2013	51360	51361	51362	51363	5	BH1
		08-11	51360	51361	51362	51363	5	BH1
LINCOLN								
Mark LT		06-08	51320	-	51322	51323	5	BH2
MKT	w/Factory Tow Package	12-15	51434	51435	51436	51437	5	BH7
		10-11	51320	-	51322	51323	5	BH2
Navigator		13-14	51430	51431	51432	51433	5	BH5
		98-12	51320	-	51322	51323	5	BH2
MERCURY								
Mountaineer	w/Factory Tow Package	02-10	51320	-	51322	51323	5	BH2
NISSAN								
Armada		04-15	51380	51381	51382	51383	5	BH1
Frontier		05-15	51380	51381	51382	51383	5	BH1
Pathfinder		05-15	51380	51381	51382	51383	5	BH1
Titan		04-15	51380	51381	51382	51383	5	BH1
Xterra		05-15	51380	51381	51382	51383	5	BH1
SATURN								
Outlook		07-09	51420	51421	51422	51423	5	BH1
TOYOTA								
4Runner		03-15	51360	51361	51362	51363	5	BH1
Land Cruiser		13-14	51360	51361	51362	51363	5	BH1
		03-11	51360	51361	51362	51363	5	BH1
Sequoia		03-14	51360	51361	51362	51363	5	BH1
Tacoma		07-15	51360	51361	51362	51363	5	BH1
Tundra		2015	-	-	51455	51456	5	BH4
		03-14	51360	51361	51362	51363	5	BH1
Harness Location Designators:								
BH1 = Underneath dash, left of steering column, near emergency brake pedal								
BH2 = Underneath dash, near center console								
BH3 = Underneath dash, in junction box left of steering column								
BH4 = Behind storage pocket, above ashtray								
BH5 = Underneath dash, behind center access panel on passenger side								
BH6 = Underneath dash, near brake pedal								
BH7 = Behind storage pocket in center of dash								
BH8 = Underneath dash, to right of emergency brake pedal								

Red text indicates products Continued While Supplies Last (CWSL).