



# INSTALLATION

## Step 1

Locate vehicle battery on the driver side under the hood and disconnect the negative battery terminal.

## Step 2

Open the vehicle tailgate. Remove storage area cover, rubber mat and spare tire cover (A).

## Step 3

Remove the D-rings on the driver and passenger sides. Remove the rear scuff panel (B).

## Step 4

Carefully pull back the driver side interior trim panel; a clip removal tool may be required. Separate the trim panel in the rear of the vehicle and work your way up and forward to locate the vehicle taillight wiring harness connectors. The connector will be similar to that on the CURT connector (C).

## Step 5

Insert the CURT wiring harness end into the vehicle harness connector. Make sure the connectors are fully inserted with locking tabs in place (D).

## Step 6

Route the remaining part of the CURT connector behind the trim panel toward the rear of the vehicle.

## Step 7

Locate a flat spot inside the vehicle, near the taillight. Adhere the black converter box using the provided double-sided tape (E).

## Step 8

When in use, route the 4-flat to the center of the vehicle. When not in use, roll up and store in a convenient, out of the way location. Secure any loose wires with the provided cable ties.

## Step 9

Reinstall all items removed during install and reconnect negative battery terminal. Install the provided 4-flat dust cover to help prevent corrosion.

