



# INSTALLATION MANUAL

## UTV-59CA

### Level of Difficulty

Easy

### Parts List

2	Turnbuckle brackets
4	Turnbuckles
4	Hex bolt, 5/16" - 18 x 1"
8	Flat washer, 5/16"
4	Nylock nut, 5/16"

### Tools Required

Socket, 1/2"	Ratchet
Wrench, 1/2"	Socket extension

### Torque Specifications

	Metric	SAE	Torque
	M6 bolt		3 ft.-lbs.
	M8 bolt		7 ft.-lbs.
	M10 bolt		16 ft.-lbs.
	M12 bolt		28 ft.-lbs.
	1/4" bolt		3 ft.-lbs.
	5/16" bolt		7 ft.-lbs.
	3/8" bolt		16 ft.-lbs.
	7/16" bolt		20 ft.-lbs.
	1/2" bolt		28 ft.-lbs.

Use above torque setting unless otherwise noted

### Product Photo



### UTV Tool box (not included)



### Notes and Maintenance

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

To protect the product, wax after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

For polished, gloss and other smooth finishes, polish may be used to clear small scratches and scuffs on the finish.

Mild automotive detergent may be used to clean the product. Do not use dish detergent, abrasive cleaners, abrasive pads, wire brushes or other similar products that may damage the finish.

Refer to the table to the left when securing hardware during the installation process to help prevent damage to the product or vehicle.

### Step 1

Place one flat washer onto each hex bolt as shown.

Place two bolts into the turnbuckle bracket and push the bolts through the center slots in the bottom of the toolbox.



### Step 2

Place a flat washer and a nylock nut on the bolt on the inside of the toolbox.

Repeat this process for the two bolts on the other side of the toolbox.



### Step 3

Tighten all four bolts making sure the bracket is pushed tight against the toolbox.

With assistance, carefully place the toolbox on UTV.



### Step 4

Attach the turnbuckles to the turnbuckle brackets and the tie-down in the UTV bed. Place two turnbuckles on each side at opposite angles.

Repeat for all four turnbuckles.

Using a wrench, tighten all turnbuckles until the toolbox is secure.

**CAUTION:** Do not over-tighten turnbuckles. Damage to UTV or toolbox may occur.



## Step 5

Congratulations on the installation of your new UWS UTV tool box.

With the tool box installed, periodic inspections should be performed to ensure all mounting hardware remains tight.

To protect your investment, see the 'Notes and Maintenance' section on the first page of this instruction manual.

If desired, tape (not included) can be placed over openings in the bottom of the toolbox to prevent dust from entering the toolbox in dusty conditions.

