


- 1. FISHWIRE  $1/4 \times 1 \times 3$  BLOCK AND 1/2" CARRIAGE BOLT THROUGH ACCESS SLOT IN FRAME AND DOWN THROUGH EXISTING REARWARD SLOT AS SHOWN ABOVE, EACH SIDE.
- 2. RAISE HITCH INTO POSITION AND FASTEN WITH LOCK WASHER AND NUT AS SHOWN ABOVE.
- 3. USING THE HITCH AS A TEMPLATE, DRILL TWO (2) 1/2" HOLES FOR FORWARD ATTACHMENTS AS SHOWN ABOVE.

1/2-13 X 1-3/4 GR5 CARRIAGE BOLT 1/4 X 1 X 3 BLOCK LOCK WASHER

- 4. FISHWIRE 1/4 X 1 X 2 BLOCK AND 1/2" CARRIAGE BOLT THROUGH ACCESS SLOT IN FRAME AND DOWN THROUGH THE DRILLED HOLE AND HITCH AS SHOWN ABOVE. BLOCK MUST LAY FLAT INSIDE FRAME.
- 5. INSTALL LOCK WASHERS AND NUTS AS SHOWN ABOVE.

TIGHTEN 1/2 GR5 FASTENERS TO 75 LB.-FT.



USE ONLY THE DRAWBAR SHOWN FOR CORRECT BUMPER CLEARANCE AND HEIGHT.

DRAWBAR MUST BE USED IN THE <u>RISE</u> POSITION ONLY.

THIS PRODUCT COMPLIES WITH SAFETY SPECIFICATIONS AND REQUIREMENTS FOR CONNECTING DEVICES AND TOWING SYSTEMS OF THE STATE OF NEW YORK, V.E.S.C. REGULATION V-5 AND SAE J684.

APPROX WEIGHT (LB.) FASTENER KIT 23.5 01130-884

NOTE: Check hitch frequently, making sure all fasteners and ball are properly tightened. If hitch is removed, plug all holes in trunk pan or other body panels to prevent entry of water and exhaust fumes. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Follow car maker's specs for maximum trailer weight and tongue weight. Do not cut access or attachment holes with a torch.

Cequent Performance Products
Plymouth, Michigan

PRINTED IN MEXICO