

2013, FORD F250/350/550, Shifter Linkage Mounting Diagram PART #701916

Important:

Manufacturer is not responsible for negligent use of vehicle with Shifter Linkage installed, including over tightening of screws and bolts causing damage to vehicle.



remove
Lower OEM bolt

loosen
Upper OEM bolt

Picture 1

Installation Instructions:

Step 1: To install your Shifter Linkage Guard, remove the lower OEM Bolt. (see picture 1)

Step 2: Loosen the upper OEM bolt and slide Guard between bracket and bolt.
(see picture 1 and 2)

Step 3: Reinstall the lower OEM bolt and tighten both bolts.

Ensure factory bolts are tight. Inspect occasionally to insure they remain tight.



Picture 2