

# 56011

HONDA ACCORD 2DR  
HONDA ACCORD 4DR  
HONDA CIVIC  
HONDA FIT  
MAZDA 3  
MAZDA CX-5  
MITSUBISHI GALANT

WIRING LOCATION GUIDE  
GUÍA DE UBICACIÓN DEL CABLEADO  
IDE D'EMPLACEMENT DES FILS



### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.



### ¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

### À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filéée.

12/17/2013



## INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813

### English

1. Open the trunk/hatch and on both sides of the vehicle remove rear access cover (A,B). Remove the vehicle's cargo floor covering and rear scuff panel (C). Inside the rear access panel locate the vehicle's taillight wiring harness. The connectors will be similar to those on the T-Connector. On the driver's side separate the connectors from the backside of the taillight assembly (D).

#### HONDA FIT ONLY

Make sure to use the blue three pin connector not the green three pin connector (E).

2. On the driver's side insert the T-Connector ends with the yellow and red wires between the separated housings (F).

3. Route the T-Connector end with the green wire out from under the driver's side trim panel across the removed scuff panel and under the passenger side trim panel. Repeat Step 2 on the passenger side using the green wire only separating the 3 pin connector.

4. On the driver's side locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided (F).

5. Adhere the black converter box to the frame of the car using the double-sided tape provided. Secure any loose parts of the T-Connector with the cable ties provided.

6. Route the 4-flat wire to the center of the vehicle and out the trunk when in use. When not in use roll up and store in an out of the way location in the rear cargo area.

#### WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

