


INSTALLATION INSTRUCTIONS

DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE'S LAMP LOAD RATING, WHICHEVER IS LOWER

56215 T-CONNECTOR KIT



WIRING LOCATION GUIDE

SUVs, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below

S4 - Behind passenger's side rear access panel



APPLICATIONS

| Make | Model |
|-------|-----------|
| Honda | Crosstour |

NOTE

All steps must be followed to ensure the T-connector will function properly. Once installed, test the function by connecting a test light or properly wired trailer.

TOOLS NEEDED

- 10mm socket
- Ratchet
- Small, flat blade screwdriver

WARNING

The battery connection must be fuse protected, 10 amp max. Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle's lamp load rating, whichever is lower.

Signal Circuits - 3.0 amps per side
Tail / Running Circuits - 6.0 amps total

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

INSTALLATION

Step 1

Access the vehicle's wiring harness connector, located in the cargo area behind the passenger's side interior trim panel. See position S4, shown in the 'Wiring Location Guide'.

Step 2

Locate the vehicle's battery on the driver's side under the hood and disconnect the negative battery terminal.

Step 3

Open the vehicle's rear hatch and remove cargo area cover and cargo storage tray (A,B).

Step 4

On the passenger's side, remove the side cargo tray by removing the 10mm bolt holding it in place (C).

Step 5

Remove the two fasteners and small center cover from the rear scuff panel. Remove rear scuff panel by pulling out on the bottom and then up (D).

Step 6

Remove the 10mm bolt and cargo tie down from the passenger's side trim panel (E).

Step 7

Pull out on the passenger's side trim panel to locate the vehicle's white trailer tow connector. The tow connector will be similar to that on the towing wiring harness (F).

Step 8

Insert the tow wiring harness housing into the vehicle's trailer tow connector. Make sure that the housings are fully inserted with the locking tabs in place (G).

Step 9

Locate a flat spot under the rear scuff panel and adhere the black converter box using the double-sided tape provided (H). Secure any loose wires of the tow wiring harness with the cable ties provided.

Step 10

Reinstall all items removed during the installation.

Step 11

Locate the vehicle's fuse box in the engine compartment, on the driver's side, near the firewall. Remove the fuse panel cover and insert the provided 15 amp fuse into fuse position 10 (I). Check vehicle owner's manual or contact the vehicle manufacturer for more information.

Step 12

Reconnect the negative battery terminal.

NOTE: When in use, route the 4-flat to the center of the vehicle. When not in use, roll up and store in a convenient, out of the way location.

