

INSTALLATION MANUAL

70140

Level of Difficulty

Easy

Installation difficulty levels are based on time and effort involved and may vary depending on the installer level of expertise, condition of the vehicle and proper tools and equipment.

Parts List

Item	Qty	Description
1	2	Tow bar lug
2	2	Clevis pin
3	2	Lynch pin

Tools Required

Torque wrench	Allen wrench, 1/4"
Ratchet	Socket, 9/16

⚠ WARNING

Never exceed the vehicle manufacturer's recommended gross vehicle weight rating (GVWR).

Product Photo



⚠ CAUTION

Take care when cutting any plastic or metal as injury may occur if done improperly.

NOTICE

Visit www.curtmfg.com for a full-color copy of this instruction manual, as well as helpful videos, guides and much more!

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

To help prevent damage to the product or vehicle, refer to the specified torque specifications when securing hardware during the installation process.

Product Registration and Warranty

CURT stands behind our products with industry-leading warranties. To get copies of the product warranties, register your purchase or provide feedback, visit: warranty.curtgroup.com/surveys

Step 1

Remove two existing tow bar lugs from the ends of the tow bar using a 1/4" Allen wrench and 9/16" socket.



Step 2

Install the new tow bar lugs (#1) onto the tow bar. Secure with the hardware removed in Step 1.



Step 3

Slide the tow bar lugs over the recovery loops, aligning the holes in the recovery loops with the holes in the lugs.

Step 4

Install a clevis pin (#2) and lynch pin (#3) into each tow bar lug (#1) as shown.

Note: When towing, attach the tow bar safety cables onto the vehicle recovery loops.

