



# INSTALLATION MANUAL

## UTV-59YV

### Level of Difficulty

Easy

### Parts List

1	Adhesive foam strip
2	Bolt, M8 x 1.25 x 25mm
2	Lock washer, M8
2	Flat washer, .344" x 1.25"
4	Flat washer, .281" x 1.25"
4	Self-tapping screw, 1/4" x 1"

### Tools Required


Ratchet	Socket extension
Wrench, 13mm	Nut driver, 3/8"
Socket, 13mm	Drill

### Torque Specifications

	Metric	SAE	Torque
	M6 bolt		3 ft-lbs.
	M8 bolt		7 ft-lbs.
	M10 bolt		16 ft-lbs.
	M12 bolt		28 ft-lbs.
	1/4" bolt		3 ft-lbs.
	5/16" bolt		7 ft-lbs.
	3/8" bolt		16 ft-lbs.
	7/16" bolt		20 ft-lbs.
	1/2" bolt		28 ft-lbs.

Use above torque setting unless otherwise noted

### Product Photo



### UTV Tool box (not included)



### Notes and Maintenance

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

To protect the product, wax after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

For polished, gloss and other smooth finishes, polish may be used to clear small scratches and scuffs on the finish.

Mild automotive detergent may be used to clean the product. Do not use dish detergent, abrasive cleaners, abrasive pads, wire brushes or other similar products that may damage the finish.

Refer to the table to the left when securing hardware during the installation process to help prevent damage to the product or vehicle.

### Step 1

If the UTV has threaded holes on the top edge of the bed, locate the second hole from the front of the box (approximately 8.75" from the front of the box). This is the closest position to the front of the cab the tool box can be mounted.

**Note:** Make sure the threaded holes are free from dirt, paint and other debris.



### Step 2

If desired, place a piece of foam or tape (not included) between the tool box and the bed rail of the UTV to protect the finish.

With assistance, carefully place the tool box onto the UTV. Open the lid of the tool box.



### Step 3

Slide the tool box forward and take note of where the tool box lid contacts the UTV frame. Place the provided foam strip onto the UTV frame where the tool box lid makes contact with the frame to protect the finish of the UTV frame and the tool box.

**Note:** If your UTV does not have threaded holes in the bed rails skip to step #5.

With the lid of the tool box open, place an M8 bolt, M8 lock washer and a .344" x 1.25" flat washer through the center slot on the tool box and into the threaded holes in the side of the UTV box.

Hand tighten the bolts and repeat this step on the opposite side of the tool box.



### Step 4

Close the tool box lid. Adjust the tool box to the desired position.

Carefully open the tool box lid and tighten both M8 bolts to the UTV manufacturer's recommended torque specifications.



## Step 5

**Note:** This step is only needed if your UTV does not have threaded holes in the box sides.

Adjust the tool box to the desired position, making sure you can access the bed rails on the UTV through the slots on the tool box and that the lid of the tool box can open freely.

Using a drill and four 1/4" self-tapping screws and four .281" x 1.25" flat washers, attach the tool box to the UTV.



## Step 6

Congratulations on the installation of your new UWS UTV tool box.

With the tool box installed, periodic inspections should be performed to ensure all mounting hardware remains tight.

To protect your investment, see the 'Notes and Maintenance' section on the first page of this instruction manual.

If desired, tape (not included) can be placed over openings in the bottom of the tool box to prevent dust from entering the tool box in dusty conditions.

