



# INSTALLATION MANUAL

## UTV-59HP

### Level of Difficulty

Easy

### Parts List

6	Rivet nut, 1/4" - 20
6	Flat washer, 1/4"
6	Lock washer, 1/4"
6	Pan head screw, 1/4" - 20 x 1"

### Tools Required


Phillips screw driver	Large pliers or rivet nut tool
Drill	Marker
Drill bit, 7/16"	

### Torque Specifications

	Metric	SAE	
	M6 bolt		3 ft.-lbs.
	M8 bolt		7 ft.-lbs.
	M10 bolt		16 ft.-lbs.
	M12 bolt		28 ft.-lbs.
	1/4" bolt		3 ft.-lbs.
	5/16" bolt		7 ft.-lbs.
	3/8" bolt		16 ft.-lbs.
	7/16" bolt		20 ft.-lbs.
	1/2" bolt		28 ft.-lbs.

Use above torque setting unless otherwise noted

### Product Photo



### UTV Tool box (not included)



### Notes and Maintenance

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

To protect the product, wax after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

For polished, gloss and other smooth finishes, polish may be used to clear small scratches and scuffs on the finish.

Mild automotive detergent may be used to clean the product. Do not use dish detergent, abrasive cleaners, abrasive pads, wire brushes or other similar products that may damage the finish.

Refer to the table to the left when securing hardware during the installation process to help prevent damage to the product or vehicle.

### Step 1

If desired, place a piece of foam or tape (not included) on the square tube of the UTV between the toolbox and the square tube to protect the finish.

With assistance, carefully place the toolbox on the UTV.


Position the toolbox in the desired location and carefully open the lid.



### Step 2

With the lid of the toolbox open, locate the three mounting slots in the bottom of the toolbox.

Mark the location of the two outer slots with a marker. Marks should be centered on the UTV box side.



### Step 3

With assistance, remove the toolbox from the UTV.

Using the drill and 7/16" drill bit, drill four holes, two on each side. Holes should be centered on the UTV rails at the locations that were marked in step 2.


Remove any tape and push four rivet nuts into the holes.

**Note:** A minimum of four mounting points is required. Extra fasteners are included if maintenance or repair is needed.



#### Step 4

Fasten the rivet nuts to the UTV side panel using a rivet nut tool or a large pliers and a screwdriver. Make sure the rivet nut is properly seated before proceeding to step 4.



#### Step 5

With assistance, place the toolbox back onto the UTV. Fasten the toolbox to the UTV using the pan head screws, lock washers and flat washers. Make sure the the fasteners are tight enough to compress the lock washers.



#### Step 6

Congratulations on the installation of your new UWS UTV tool box.

With the tool box installed, periodic inspections should be performed to ensure all mounting hardware remains tight.

To protect your investment, see the 'Notes and Maintenance' section on the first page of this instruction manual.

If desired, tape (not included) can be placed over openings in the bottom of the toolbox to prevent dust from entering the toolbox in dusty conditions.

